

TS-Edit Attribute Menu References

TS-UID: (input/display field) – prompts user to input a TS-UID field value. This value is should be entered the same way it is displayed on the maps. Input for the TS-UID field is required, and the menu interface will not dismiss without one (refer to the *Error* display field note below).

OK (button) – dismisses the box and returns to the parent AML.

Ownership: (input/display field) – prompts the user to specify the owner (NCDOT or municipality) of the traffic light. The list includes the NCDOT (default) and all other municipalities that have traffic light ownership within the given division. Input is not required for this field. The choice must be 'clicked' before it is populated into the database, regardless if it is highlighted.

Error (display field) – there is a display field below the 'OK' button not visible in the figure above. The field displays an error message when the user tries to dismiss the button while the TS-UID value is null. Refer to the *User Operations* section of this document for more details.

TS-EDIT Display Symbology




Fig.3: The initial ts-edit display window showing roads for Division 5

Red arcs – divXrd features (roads)

White points – ts-divX features